



9

8

10

11

12

7

®

6

5

Meowsic®

2 to 6 Years

I

FUNCTIONS

2

3

4

I. ON/OFF SWITCH

5. RETRACTABLE CORD BUTTON

10. CHILDREN'S SONGS

Slide to turn on or off. Kitty keyboard turns off Push button to retract the microphone cord.

20 pre-recorded melodies. Press clef automatically to conserve batteries—you'll button again to jump to next song.

hear it start pu-r-r-r-ing when it goes to sleep.

6. BEAT SOUNDS

Typical beats for 5 styles of music.

II. INSTRUMENT SOUNDS

2. VOLUME CONTROL

7. MICROPHONE

4 different instruments give their sounds Left arrow lowers volume.
Right arrow increases it.

to the piano keys.

Amplifies voice so child can sing along **3. TEMPO CONTROL**

to keyboard or pre-recorded songs.

12. MEOW!

Left arrow slows music down.

Right arrow speeds things up.

8. CAT SONGS

keyboard into a kitty concert. Every note 7 feline renditions of popular children's songs.

gets played in “meow.”

4. RECORD & PLAY BACK FEATURE

Press cat button again to jump to next song.

Press record. When red light comes on, any tune you play will be recorded (up to 50

9. STOP BUTTON

notes). Record until light starts blinking.

Stops whatever is playing. Ends record/replay Press play to hear your recording.

sequences, beat sounds, children and cat songs.

BX1025

®

Meowsic®

2 to 6 Years

REPLACING BATTERIES

**electromagnetic interference. Simply turn it back on 4 AA (1.5V)
BATTERIES INCLUDED**

© 2016 Maison Joseph Battat Ltd.

again to reset. Change location if problem persists.

B. and Meowsic and Just B. Just You. B. You are registered trademarks of Maison Joseph Battat Ltd.

B. curious. (Curiosity does Manufactured for Maison Joseph Battat Ltd.

not harm the Meowsic.) or rechargeable (nickel-cadmium) batteries.

Visit mybtoys.com. If you have any **earth911.com** to questions, comments or you just want quickly find the recycling center nearest you.

to play us a song, call us (toll free).

I-866-665-5524